

# **MSS1000 Series User Manual**

## **Soft Starter**

---

Please hand the manual to ultimate user, and keep  
it for future reference

---

# Preface

Thank you for choosing the LCD intelligent soft starter produced by our company. In order to give full play to the function of this product, before using, please read this manual carefully. Please operate and use correctly according to the procedures, And ensure the safety of the operator, When you find difficult problems in use and this manual cannot provide solutions, Please contact our company or local agents and dealers, We will serve you wholeheartedly.

## Safety precautions

1. The soft start shall be installed or guided by professional technicians.
2. The power and specification of the motor shall be matched with the soft start as far as possible.
3. It is forbidden to connect capacitors at the output end (u.v.w) of soft start.
4. The input and output connecting wires with the soft starter shall be wrapped with insulating tape.
5. The shell of soft starter must be reliably grounded.
6. During equipment maintenance, the input power must be cut off first.
7. The internal circuit board has high voltage. Do not repair it by nonprofessionals.

# Contents

Preface .....	1
Contents.....	1
1. Function and characteristic of MSS1000 series soft starter.....	1
1.1 MSS1000 series soft starter function .....	1
1.2 Features of MSS1000 series soft starter .....	1
2. Product Model and inspection.....	2
3. Conditions of use and installation.....	3
3.1 Conditions of use .....	3
4. How it works .....	3
5. Basic Connection and external terminal .....	4
5.1 Schematic diagram of terminal wiring of soft starter .....	4
5.2 Secondary terminal sequence diagram of soft starter.....	5
5.3 Specification of soft starter external terminal .....	5
6. Keyboard function and operation .....	7
7. Soft starter parameter list.....	8
8. Specification of soft starter parameters.....	12
8.1 Soft start.....	12
8.2 Stop Mode.....	15
8.3 Type Selection of soft starter .....	15
8.4 Overload protection .....	15
8.5 Current arrival function.....	16
8.6 Analog current output function .....	17
8.7 Screen saver time .....	18
8.8 Screen contrast.....	18
8.9 Communication function.....	18
9. Failure protection function and solution.....	24
10. Trial Operation and daily maintenance of soft starter .....	26
10.1 Test run inspection and points for attention.....	26
10.2 Matters needing attention in daily maintenance.....	27
Notice of order.....	28
11. Structure and outline dimensions of MSS1000-G on-line intelligent soft starter .....	28
12. Structure and outline dimensions of MSS1000 bypass intelligent soft starter .....	29
13. External dimensions of MSS1000 intelligent soft starter with built-in bypass (N type).....	30
14. Specification parameter list of peripheral parts.....	30
Product Warranty Card .....	31

# **1. Function and characteristic of MSS1000 series soft starter**

The Smart AC motor soft Starter is a new type of motor starting equipment which is designed and produced with power electronic technology, microprocessor technology and modern control theory. This product can effectively limit the starting current of asynchronous motor when starting. It can be widely used in fans, pumps, conveyors, compressors and other loads. It is an ideal replacement product for traditional star/triangle conversion, self-lotus voltage-reducing, magnetic control voltage-reducing and other voltage-reducing starting equipment.

## **1.1 MSS1000 series soft starter function**

1. Reduce the starting current of the motor, reduce the distribution capacity and avoid capacity investment.
2. Reduce the starting stress and prolong the service life of motor and related equipment. The smooth starting and soft stopping can avoid the surge and water hammer effect of traditional starting equipment.
3. A variety of starting mode and wide range of current, voltage settings, can adapt to a variety of load occasions, improve the process.
4. Improve the reliable protection function, more effective protection of motor and Related Equipment Safety.
5. Can be used for frequent starting and stopping occasions.


## **1.2 Features of MSS1000 series soft starter**

1. The MSS1000 series AC motor soft starter uses high performance microprocessor technology for higher performance and wider voltage adaptation.
2. 6 kinds of starting mode can be chosen, which can make the motor realize the best starting effect.
3. Original swing starting mode, good starting effect for centroid eccentric load.
4. It can realize the function of positive and negative rotation, and the motor can operate with positive and negative rotation.
5. Two parking mode can be chosen: Free Parking, soft parking,
6. On-line type and by-pass type can be set freely.
7. Two drive modes can be selected: torque mode and smooth mode
8. Two independent programmable output relays: It is convenient to realize interlock control with other devices, and has delay action function, delay time is adjustable.
9. The three-phase current value can be displayed at the same time, and the current

- value can be calibrated independently.
10. Large screen LCD machine interface, Chinese (Chinese display) and English two display modes, easy to operate.
  11. Multiple protection monitoring functions, heat overload protection according to load requirements adjustable grade, multiple protection functions can be opened and closed independently.
  12. The last 12 failure records can be checked to provide the basis for failure analysis.
  13. A set of 4 ~ 20mA (0 ~ 20mA) analog outputs.
  14. MODBUS RTU communication (RS485) is available. You can set parameters, operate and monitor by computer software.
  15. Actual Power Setting: When the power of the soft starter is larger than the actual load power, the rated current of the soft starter can be set according to the actual load to match the actual power of the soft starter with the load, to ensure the start, operation, protection and other parameters of the accuracy.

## 2. Product Model and inspection

Before leaving the factory, all the functions and running tests of each AC motor soft starter are carried out. After receiving the equipment, users should check the following steps. If you find any problem, please contact the supplier immediately. CHECK THE PRODUCT NAMEPLATE: Make sure the goods you received are in accordance with the products you ordered.



Check whether the product is damaged during transportation, such as: internal parts falling off, Shell sinking, deformation and line falling off.

Product qualification certificate and Operation Manual: Each soft starter is provided with one product qualification certificate and one operation manual.

## 3. Conditions of use and installation

### 3.1 Conditions of use

The service condition has certain influence to the soft starter's normal service and the service life, therefore please install the soft starter in the place which meets the following service condition.

Power supply: City Power, self-contained power stations, diesel generator;

INPUT VOLTAGE: AC380V, 660V, 1140V (- 10% ~ + 15%) , 50Hz/60Hz;

Applicable Motor: General squirrel-cage Induction Motor (please specify when ordering winding motor) ;

Starting Times: The Standard Product is recommended to start and stop no more than 15 times per hour

Cooling Mode: Forced Cooling (on-line thyristor)/Natural Cooling (by-pass) ;

INSTALLATION: Wall hanging type, Cabinet Body Type;

Conditions of use: the intelligent AC motor soft starter should be equipped with bypass contactor;

Protection level: IP20 (55KW and below)/IP00 (75KW and below);

Environmental conditions: altitude below 2000 meters, more than 2000 meters to reduce capacity use; the ambient temperature is between -25°C and 40°C;


Relative humidity: not more than 95% (20 °C ± 5 °C)

Pollution Environment: no flammable, explosive, corrosive gases, no conductive dust;

Ventilation vibration: Indoor installation, good ventilation, vibration less than 0.5 g;

## 4. How it works


The MSS1000 series intelligent AC motor soft starter uses three pairs of antiparallel thyristors connected in series to the electronic circuit of the AC motor. By using the function of electronic switch of thyristor and controlling the change of trigger angle of thyristor by microprocessor, the opening degree of thyristor can be changed, thus the input voltage of motor can be changed, so as to control the soft starter of motor. When the starting is completed, the soft starter output reaches the rated voltage. At this point, the three-phase by-pass contactor KM is automatically controlled by the by-pass control signal, and the motor is put into power grid operation.



figuer 4-1

## 5. Basic Connection and external terminal


### 5.1 Schematic diagram of terminal wiring of soft starter



figuer 5-1

Note: built-in bypass and on-line soft starters do not have L1, I2, L3 terminals and do not require external ac contactors KM.

## 5.2 Secondary terminal sequence diagram of soft starter



figuer 5-2

Note 1: Terminal ①-⑩ internal power supply, only the external access to the switch volume, does not need to access the power supply.

Note 2: Terminal ⑫- ⑳ need to provide external power and load indicator circuit diagram, etc.




figure 5-3

Note: There are two kinds of connection modes for external control start-stop signal. When two-wire control is used, the stop end is connected with the start end.

## 5.3 Specification of soft starter external terminal

Terminal type	Terminal number	Terminal Name	Description
Main circuit	R、S、T	Power input	Soft starter three-phase electric power input
	U、V、W	Soft starter output	Connect three-phase asynchronous motor
	L1、L2、L3	By-pass contact terminal	For use with bypass contactors. Only the external bypass type soft starter has this terminal, the built-in bypass type and thyristor on-line type soft



				starter does not have this terminal.
Control loop	Digital input	1	External starting	The soft starter can be started by short connection with the Common Terminal (5,6)
		2	The external controls are down	Disconnect from Common Terminal (5,6) to stop soft starter
		3	External instantaneous shutdown	The utility model is short connected with a common terminal (5,6) and can be started by a soft starter
		4	External Control Reset	In case of failure, Short connection with Common Terminal (5,6) can clear the failure state
		5	Digital Input Common Terminal	Digital Input Terminal Common Terminal
		6		
	Analog output	7	4-20mA output positive	4-20mA output and 20mA corresponding current can be adjusted by parameters C10, C11 and C12
		8	4-20mA output negative	
	Communication	9	RS485+	Used in Modbus RTU communication
		10	RS485-	
	Stand by	11	Stand by	No function, reserve
	Programming Relay 1	12	Programming Relay 1 normally on	Programmable output can be selected from the following features 0.No movement 1.Up Action 2.Soft start
		13	Programming Relay 1 common	

		14	Programming Relay 1 normally closed	3.Bypass Action 4.Soft Stop 5.Point Action 6.Runtime action
	Programming Relay 2	15	Programming Relay 1 normally on	7.Standby Action 8.Malfunction action 9.Thyristor breakdown action 10.Current greater than arrival value 1
		16	Programming Relay 1 common	11.Current greater than arrival value 2
		17	Programming Relay 1 normally closed	12.Current less than arrival value 1 13.Current less than arrival value 2
	Bypass relay	18	By-pass relay always on	By-pass Operation Suction
		19	By-pass relay common	
		20	By-pass relay normally closed	

## 6. Keyboard function and operation

The soft starter uses the large screen liquid crystal display module and the micro-movement type key to constitute the Operation Display Keyboard, 6 micro-movement type keys. It can realize the start, stop operation, parameter equipment, modification, fault inquiry, fault reset and so on. See figure 6-1 for details.



Figure 6-1

Soft starter door panel opening dimensions 112 \* 89 mm

1. Press the "PGR" key to enter the parameter group and press  $\triangle$  or  $\nabla$  to switch the parameter group.
2. Parameter modification, press the "PRG" key to enter the parameters, press  $\triangle$  or  $\nabla$  to modify the parameter value. Then press the "PRG" key to save the parameters, press the "return" key to return to the main interface.
3. Press the "Run" button to start the soft starter.
4. Press "Stop" to stop the machine.
5. Press the "Return" button to view the failure record while the machine is in standby mode.
6. Long press the  $\triangle$  key, there will be 2 options: OK and ESC. OK means clear the fault record, ESC: not clear.
7. Long-press the  $\nabla$  key, there will be 2 options: OK and ESC. OK means reset, ESC: not reset.
8. 7. Soft starter parameter list

Principal term	Code	Subordinate term	Parameter	Default value	Notes	Attribute
A Basic parameter	A00	Control Mode	0: Do not start or stop 1: Keyboard control 2: External Control 3: Keyboard + external control 4: Communication control 5: Keyboard+communication 6: External control + communications 7: Keyboard + external control + communication	3: Keyboard +external control		
	A01	Starting Mode	0: Current limiting start 1: Voltage ramp start 2: Break-through voltage ramp start 3: Retentions	0: Current limiting start		
	A02	Starting current limiting	50%~600%	300%		

		percentage				
	A03	Percentage of starting voltage	10%~80%	35%		
	A04	Voltage ramp starting time	1s~120s	15s		
	A05	Surge voltage	10%~95%	80%		
	A06	Pop-up time	10ms~2000ms	500ms		
	A07	Stop Mode	0:Free Parking 1:Soft parking	0:Free Parking		
	A08	Soft Stop Time	1s~60s	5s		
	A09	Soft starter type	0:On-line type 1:Bypass type	1:Bypass type		
B Basic parameter	B00	Starting overload level	0~30	10	0:Shut down	
	B01	Run overload level	0~30	10	0:Shut down	
	B02	Run-over multiple	0%~600%	0%	0:Shut down	
	B03	Run overcurrent protection time	0s~6000s	5s		
	B04	Overvoltage protection value	100%~140%	120%	100:Shut down	
	B05	Overvoltage protection time	1s~60s	5s		
	B06	Under voltage protection value	60%~100%	80%	100:Shut down	
	B07	Under voltage protection time	1s~60s	5s		
	B08	Three-phase unbalance	20%~100%	40%	100:Shut down	
	B09	Three-phase unbalance	0.1s~60.0s	10.0s		

		time				
	B10	Start Timeout	0s~150s	60s	0:Shut down	
	B11	Click timeout	0s~150s	0s	0:Shut down	
	B12	Under load protection value	0%~100%	0%	0:Shut down	
	B13	Protection time under load	1s~60s	10s		

Principal term	Code	Subordinate term	Parameter	Default value	Notes	Attribute
C Basic parameter	C00	Programmable relay1	FEATURES: 0:No movement 1.Up Action 2.Soft start 3.Bypass Action 4.Soft Stop 5.Point Action 6.Runtime action 7.Standby Action 8.Malfunction action 9.Thyristor breakdown action Delay:0-600s	8:Malfunction action		
	C01	Programmable output delay1		0s		
	C02	Programmable relay2		6:Runtime action		
	C03	Programmable output delay2		0s		
	C04	Correspondence address	1~127	1		
	C05	Communication Baud rate	0:2400 1:4800 2:9600 3:19200	2:9600		
	C06	A Phase current calibration	10%~1000%	100%		
	C07	B Phase current calibration	10%~1000%	100%		
	C08	C Phase current	10%~1000%	100%		

		calibration				
	C09	AB Calibration value of phase voltage	10%~1000%	100%		
	C10	4-20mA Lower bound calibration	0%~150.0%	20.0%		
	C11	4-20mA Upper bound calibration	0%~150.0%	100.0%		
	C12	4-20mA Upper bound current	50%~500.0%	200%		
D Basic parameter	D00	Soft starting rated current		A		
	D01	Soft starting rated voltage		V		
	D02	Rated current of motor		A		
	D03	Soft Start Times				
	D04	Cumulative running time				
	D05	Master software version		V3.13		
	D06	User Password	000000	0		
E Basic parameter	E00	Standby display mode	0:Patterns 0 Single-phase current display 1:Patterns 1 Three-phase current display	0:Patterns		
	E01	Run display mode	0:Patterns 0 Single-phase current display 1:Patterns 1 Three-phase current display	0:Patterns		
	E02	Operating language selection	0:English 1:Chinese	1:Chinese		
	E03	Screen saver time	0s~1800s	120s	0:No prote ction	

	E04	Keyboard software version				
	E05	Screen contrast	0~115			

Note:

○: Indicates that the parameter value can be modified when the soft starter is stopped and running.

◎: Indicates that this parameter value cannot be modified while the soft starter is running.

●: Indicates that the parameter value is a read-only parameter and cannot be modified.

## 8. Specification of soft starter parameters

### 8.1 Start method

The AC motor soft starter has the following 6 starting modes, which users can choose according to their load conditions.

0: Current limiting start

1: Voltage ramp start

2: Jump current limiting start

3: Surge voltage ramp start

4: Point start

5: Swing Start (reserved)

All start modes except point start are subject to B11 start timeout limit, soft starter reports start timeout failure and stops when the start time exceeds the start timeout limit, and B11 is set to 0, that turns off the start-up timeout protection.

#### 8.1.1 Current limiting start

After starting, the motor current quickly rises to the set current Value  $I_m$ , and keeps the output current not more than this value, so that the motor gradually increases, when the motor is close to the rated speed, the motor current quickly drops to the rated current  $I_e$ , completing the starting process, figure 8-1.

The current limiting starting mode is usually used in the situation where the starting current is strictly required, especially when the power grid capacity is relatively small. When the starting capacity is to be limited, the current limiting multiple can be set according to the requirements, generally between 2.5 and 3 times, too small a setting can also cause a failure to start properly. When current-limiting starting is adopted, the starting time is related to the current-limiting multiple, the larger the current-limiting multiple, the shorter the starting time, and vice versa.

Parameters related to "Current limiting start":

A01. Starting Mode, A02. Starting current limiting percentage




figure 8-1

### 8.1.2 Voltage ramp start

After starting, the output voltage of the soft starter rises rapidly to the “Starting voltage” value  $U_1$ , and then gradually increases the output voltage according to the “Voltage ramp starting time” until the starting is completed, as shown in figure 8-2.

Voltage ramp starting mode is suitable for inertia load, or the starting current requirements are not strict, but the starting stability requirements are higher occasions. This starting mode can greatly reduce the starting impact and mechanical stress. The larger the initial voltage  $U_1$  is, the larger the initial torque is, but the larger the impact is. The voltage ramp starting is also controlled by the limited current starting multiple, that is, the starting current will not exceed the starting limit current value during the voltage ramp starting. This measure is to prevent the system from damage caused by improper parameter setting, therefore, the starting current limit should be raised properly when using voltage ramp mode. The length of the starting process is related to the setting value of the starting time and the weight of the load.

Parameters related to “VOLTAGE RAMP START”:

A 01. Starting Mode, A 03. Starting voltage percentage, A 04. Voltage ramp start time, A 02. Starting current limiting percentage




figure 8-2



### 8.1.3 Jump current limiting start

Some static resistance of the load, in the moment to start a larger Torque, also can start normally; you can choose this starting mode. Start, soft starter instantaneous output a higher voltage (time can be set) , so that the motor rotation, and then according to the current limit start mode starting, until the completion of starting, as shown in figure 8-3.

Parameters related to "JUMP CURRENT LIMITING START":

A01. Starting Mode,

A 02. Starting current limiting percentage

A05. Surge voltage

A06. Pop-up time




Figure 8-3

### 8.1.4 Surge voltage ramp start

Some static resistance of the load, in the moment to start a larger Torque, also can start normally; you can choose this starting mode. When starting, soft starter instantaneous output a higher voltage (time can be set) , so that the motor rotation, and then according to the voltage ramp starting mode, until the completion of starting, as shown in figure 8-4.

Parameters related to "JUMP VOLTAGE RAMP START":

A01. Starting Mode

A03. Starting voltage percentage

A04. Voltage ramp start time

A02. Starting current limiting percentage

A05. Surge voltage

A06. Pop-up time




Figure 8-4

## 8.2 Stop Mode

The soft starter has the following two stop modes:

- 0: Free Parking
- 1: Soft parking

### 8.2.1 Free Parking

When receiving the Stop Command, soft starter control bypass contactor disconnects, at the same time, block the main circuit thyristor output voltage, motor according to inertia gradually stop.

### 8.2.2 Soft parking

In this shutdown mode, the motor power supply is switched from the by-pass contactor to the main circuit thyristor, and the control output voltage gradually decreases until the motor stops smoothly. The model is generally used to prevent the vertical water supply pipeline equipment in the moment of Horizontal Stop Water Hammer Phenomenon, to extend the service life of pipeline valves.

The parameters associated with "Soft parking" are:

A07. Stop Mode, A08 soft stop time

## 8.3 Type Selection of soft starter

You can choose online or bypass type by parameter A09. On-line soft starter saves the trigger state of the cassette tube in the running state, which is used for the on-line operation of the soft starter. The trigger state is saved by the thyristor in the running state of the online soft starter, which is used for the on-line work of the soft starter. In by-pass type (including built-in bypass and external bypass), the thyristor

stops triggering in the running state, and the bypass contactor is responsible for turning on the main circuit when the motor runs at full voltage.

## 8.4 Overload protection

Anti-time limit control is used for overload protection

Duration of protection:

Where: T for action time, TP for protection level, I for running current, Ip for motor rated current.

Motor overload protection characteristic curve: figure 8-5




Figure 8-5

Characteristics of motor overload protection

Overload Multiplier overload level	1.05Ie	1.2Ie	1.5Ie	2Ie	3Ie	4Ie	5Ie	6Ie
1	∞	79.5s	28s	11.7s	4.4s	2.3s	1.5s	1s
2	∞	159s	56s	23.3s	8.8s	4.7s	2.9s	2s
5	∞	398s	140s	58.3s	22s	11.7s	7.3s	5s
10	∞	795.5s	280s	117s	43.8s	23.3s	14.6s	10s
20	∞	1591s	560s	233s	87.5s	46.7s	29.2s	20s
30	∞	2386s	840s	350s	131s	70s	43.8s	30s

∞: It means no movement

## 8.5 Current arrival function

The current reaching function is used with two multi-function relays, which are divided into two modes: current greater than reaching value action and current less than reaching value action.

In current-over-arrival mode, the relay operates when the operating current is greater than the current reached a set value, and resumes when the operating current is less than (current-current-to-return differential) , as shown in figure 8-6.

In current-less-than-arrival mode, the relay operates when the operating current is less than the current reached the set value, and recovers when the operating current is greater than (current-to-reach + current-to-return difference) , as shown in figure 8-7.

The parameters associated with the “Current arrival function “are:

C00: Programmable relay1;	C01: Programmable output delay1
C02: Programmable relay2;	C03: Programmable output delay2;
C06: Electrical Current1	C07: Current return differential1
C 08: Current arrival2	C 09: Current return2.




Figure 8-6




Figure 8-7

FIGURE:  $I_1$  represent the current arrival value and  $I_h$  represents the return current, On means relay action, OFF means relay recovery.

## 8.6 Analog current output function

The analog current output function can realize the analog current output function of 4-20mA, 0-20mA, etc. .

C10.4-20MA lower limit calibration: used to set the upper limit of analog current

output, 20% means 4mA.

C11.4-20MA UPPER LIMIT CALIBRATION: for setting analog current output upper limit value, 100% means 20mA.

C12.4-20MA upper limit current: used to set the upper limit of analog current output corresponding to the soft starter current.

“Analog current output “parameter setting example:

Example 1, 20mA corresponds to 2 times rated current of motor, 4mA CORRESPONDS TO 0A

C12=200%, C10=20%, C11=100%

Example 2, 20mA corresponds to 1 times rated current of motor, 4mA CORRESPONDS TO 0A

C12=100%, C10=0%, C11=100%

Note: Parameters C10 and C11 can also be used for fine tuning if the analog current output is biased.

## 8.7 Screen saver time

Screen saver time is used to set the screen backlighting time. After the last operation of the keyboard, after the E03 screen saver time, the screen backlight is turned off to save energy and delay the life of the screen backlight. The screen saver time is set to 0 to turn off this feature, and the screen always remains lit.

## 8.8 Screen contrast

You can set screen contrast by parameter E05.

## 8.9 Communication function

Soft starter can be built-in Modbus RTU communication function, communication protocol please see the communication manual.

MODBUS address	Function name	Set Range	Default value	Notes
0x0000	Control Mode	0: Do not start or stop 1: Keyboard control 2: External Control 3: Keyboard + external control 4: Communications 5: Keyboard + communication	3: Keyboard + external	

		6: External control + communications 7: Keyboard + external + communication		
0x0001	Starting Mode	0: Current limiting start 1: Voltage ramp start 2: Break-through voltage ramp start 3: Retentions	0: Current limiting start	
0x0002	Starting current limiting percentage	50%~600%	300%	
0x0003	Percentage of starting voltage	10%~80%	35%	
0x0004	Voltage ramp starting time	1s~120s	15s	
0x0005	Surge voltage	10%~95%	80%	
0x0006	Pop-up time	10ms~2000ms	500ms	
0x0007	Point-to-action mode	0:Depressurization mode 1:Forward 1(4DF) 2:Forward 2(7DF) 3:Forward 3 4:Down Reversal 1(5DF) 5:Down Reversal 2(8DF) 6:Down Reversal 3)	0:Depressurization mode	
0x0008	Actuated voltage	10%~40%	40%	
0x0009	Low-frequency point dynamics	10%~100%	50%	
0x000A	Number of Oscillations	1~4	1	
0x000B	One swing start time	1s~120s	5s	
0x000C	One swing stop time	1s~120s	5s	
0x000D	Second Swing Start Time	1s~120s	5s	
0x000E	Stopping time of Secondary Oscillation	1s~120s	5s	

0x000F	Three swing start time	1s~120s	5s	
0x0010	Three-swing stop time	1s~120s	5s	
0x0011	Four swing start time	1s~120s	5s	
0x0012	Four-swing stop time	1s~120s	5s	
0x0013	Stop Mode	0:Free Parking 1:Soft parking	0:Free Parking	
0x0014	Soft Stop Time	1s~60s	5s	
0x0015	DC Brake Force	10%~100%	40%	

0x0016	DC braking time	2s~120s	10s	
0x0017	Current arrival1	1%~600%	100%	
0x0018	Current Return1	1%~100%	20%	
0x0019	Current arrival2	1%~600%	70%	
0x001A	Current Return2	1%~100%	20%	
0x001B	Soft starter type	0:On-line type 1:Bypass type	1:Bypass type	
0x001C	Programmable relay1	FEATURES: 0:No movement 1.Up Action 2.Soft start 3.Bypass Action 4.Soft Stop 5.Point Action 6.Runtime action 7.Standby Action 8.Malfunction action 9.Thyristor breakdown action	8:Malfunction action	
0x001D	Programmable output delay1	0~600s	0s	
0x001E	Programmable relay2	FEATURES: 0:No movement 1.Up Action 2.Soft start 3.Bypass Action 4.Soft Stop 5.Point Action 6.Runtime action 7.Standby Action 8.Malfunction action	6:Runtime action	

		9.Thyristor breakdown action		
0x001F	Programmable output delay1	0~600s	0s	
0x0020	Stand by			
0x0021	Stand by			
0x0022	Stand by			
0x0023	A Phase current calibration	10%~1000%	100%	
0x0024	B Phase current calibration	10%~1000%	100%	
0x0025	C Phase current calibration	10%~1000%	100%	
0x0026	AB Calibration value of phase voltage	10%~1000%	100%	

0x0027	Stand by			
0x0028	Stand by			
0x0029	4-20mA Lower bound calibration	0%~150.0%	20.0%	
0x002A	4-20mA Upper bound calibration	0%~150.0%	100.0%	
0x002B	4-20mA Upper bound current	50%~500.0%	200%	
0x002C	Fast overcurrent protection value	0%~800%	500%	0 It means no protection
0x002D	Starting overload level	0~30	10	0 It means no protection
0x002E	Run overload level	0~30	10	0 It means no protection
0x002F	Stand by			
0x0030	Stand by			
0x0031	Run-over multiple	0%~600%	0%	0 It means no protection
0x0032	Run overcurrent protection time	0s~6000s	5s	
0x0033	Overvoltage protection value	100%~140%	120%	100 It means no protection
0x0034	Overvoltage protection time	1s~60s	5s	
0x0035	Under voltage	60%~100%	80%	100 It means



	protection value			no protection
0x0036	Under voltage protection time	1s~60s	5s	
0x0037	Three-phase unbalance	20%~100%	40%	100% It means no protection
0x0038	Three-phase unbalance time	0.1s~60.0s	10.0s	
0x0039	Start Timeout	0s~150s	60s	0 It means no protection
0x003A	Click timeout	0s~150s	0s	0 It means no protection
0x003B	Under load protection value	0%~100%	0%	0 It means no protection
0x003C	Protection time under load	1s~60s	10s	
0x003D	Correspondence address	1~127	1	
0x003E	Communication Baud rate	0:2400 1:4800 2:9600 3:19200	2:9600	
0x003F	Communication Mode	n,8,1		
0x0040	Frequency down start time			
0x0041	Frequency reduction starting power			
0x0042	Down starting frequency			
0x0043~ 0x0063	Stand by			
0x0064	Soft starting rated current			Read only
0x0065	Soft starting rated voltage			Read only
0x0066	Rated current of motor			
0x0067	Soft Start Times			Read only
0x0068	Cumulative running time			Read only
0x0069	Master software version			Read only

0x006A	User Password			Read only
0x006B~ 0x006F	Stand by			
0x0100	Soft starter status			Read only
0x0101	Current fault			Read only
0x0102	Average voltage			Read only
0x0103	Average current			Read only
0x0104	Percentage of output voltage			Read only
0x0105	Percent Average current			Read only
0x0106	Apparent power value			Read only
0x0107	Three-phase current unbalance			Read only
0x0108	A Phase current value			Read only
0x0109	B Phase current value			Read only
0x010A	C Phase current value			Read only
0x010B	AB Phase voltage value			Read only
0x010C	BC Phase voltage value			Read only
0x010D	CA Phase voltage value			Read only
0x010E	Current elapsed time (minutes)			Read only
0x010F~ 0x011F	Stand by			
0x0120	Fault record1			Read only
0x0121	Fault record2			Read only
0x0122	Fault record3			Read only
0x0123	Fault record4			Read only
0x0124	Fault record5			Read only
0x0125	Fault record6			Read only
0x0126	Fault record7			Read only
0x0127	Fault record8			Read only
0x0128	Fault record9			Read only
0x0129	Fault record10			Read only

0x012A	Fault record11			Read only
0x012B	Fault record12			Read only
0x012C 0x012F	Stand by			
0x0130	Control Command Register	0x0001 Start up 0x0003 Stop 0x0004 Clear the fault		Just write

## 9. Failure protection function and solution

No.	Fault	Possible Cause	Solution
1	Input Phase loss	Incoming power phase loss	Check the three-phase power supply if there is a lack of phase? Check if power supply wire is connected and If the circuit breaker is good?
2	Output Phase	Inferior notch phase	Check if the motor wiring is good, and whether there is fault in the motor.
3	Running overload	1、Motor overload start 2、Incorrect Motor rating current setting 3、The overload level selection is inappropriate 4、The current reading is inaccurate	1、Check if there is overload 2、Check if parameter D02 is set correctly 3、Check if parameter B01 is set properly 4、Adjust parameters C06, C07, C08 to make the three-phase display current of soft starter accord with the actual current
4	Starting overload	1、Motor overload operation 2、Incorrect Motor rating current setting 3、The run overload level selection is not appropriate 4、The current reading is inaccurate	1、Check the load situation, whether there is overloading phenomenon 2、Check that the parameter D02 is set correctly 3、Check whether the parameter B00 is set properly 4、Adjust parameters C06, C07, C08 to make the three-phase display current of soft starter accord with the actual current
5	Starting	1、Motor underload	1、Adjust parameters B12 and B13

	underload	parameter setting is not correct 2、The current reading is inaccurate	to appropriate values 2、Adjust parameters C06, C07, C08 to make the three-phase display current of soft starter accord with the actual current
6	Current imbalance	1、There's something wrong with the motor coil 2、Faulty connection of main line terminal 3、The current reading is inaccurate	1、Replacement or repair of motor 2、Tighten the terminals again 3、Adjust parameters C06, C07, C08 to make the three-phase display current of soft starter accord with the actual current
7	Softens and overheats	1、Soft starter starts too often 2、The external temperature of soft starter is too high 3、The soft starter is surrounded by larger heating devices and is too compact to be mounted	1、Increase the start interval, wait for the soft starter to cool before the next start, or add a cooling device to cool down the soft starter faster 2、Improve the soft starter of the external environment, or for the use of capacity reduction 3、Improve the layout or strengthen the cooling intensity in the cabinet
8	Overvoltage fault	1、The power supply voltage is too high 2、The current reading is inaccurate	1、Adjust the supply voltage of the transformer 2、Adjust the parameter C09 to make the display voltage of the soft starter consistent with the actual voltage
9	Under voltage fault	1、Power supply voltage is too low 2、The current reading is inaccurate	1、Adjust the transformer power supply voltage; check the incoming cable is too small, check the power margin of the transformer is too small 2、Adjust the parameter C09 to make the display voltage of the soft starter consistent with the actual voltage
10	Thyristor breakdown	Two-phase thyristor breakdown, soft starter in the state of shutdown current flow	The fault will be reported if there is current in the shutdown state, power cut off, check whether there is breakdown phenomenon of two-phase thyristor
11	Start Timeout	The start time exceeds the B10 setting	1、Check that the B10 setting is appropriate

			2、 Check if the load is too heavy and the starting time is too long 3、 Adjust the starting parameters properly to shorten the starting time
12	Click timeout	Click time exceeds B11 setting value	1、 Check that the B10 setting is appropriate 2、 Shorten point-to-action time parameter B11
13	Running overcurrent	1、 Running current is too high 2、 Incorrect setting of motor rated current 3、 The run-through value is not set correctly 4、 The current reading is inaccurate	1、 Check the load situation, whether there is overloading phenomenon 2、 Check that the parameter D02 is set correctly 3、 Check whether the parameter B02, B03 is set properly 4、 Adjust parameters C06, C07, C08 to make the three-phase display current of soft starter accord with the actual current
14	Internal fault	Soft starter sending internal hardware failure	Try to re-power to see if it is resolved, if it is not resolved please contact the manufacturer

## 10. Trial Operation and daily maintenance of soft starter

### 10.1 Test run inspection and points for attention

In order to run safely before electrification should be checked in accordance with the following terms.

- ※ Does the soft start power match the motor power? It is available through D02. Motor rated current item, according to the motor nameplate current value set.
- ※ Does the motor insulation meet the requirements?
- ※ Is the input and output wiring of the main circuit correct?
- ※ Is the input and output wiring of the main circuit correct?
- ※ Check with multimeter whether there is short circuit in the three-phase power supply (R, S, T) ?
- ※ After power-on, display “Stand-by” means in the normal state of ready to start,

you can use the “Point to move” way to check whether the motor steering is correct, if not correct, replaceable motor end arbitrary two-phase.

- ※ During the trial operation, if the starting state of the motor is not ideal, the starting and stopping parameters can be set according to the parameter list, and the starting mode and parameters such as current, voltage and time can be modified accordingly.
- ※ If the fault protection appears in the whole process of power supply and operation, the fault state will be displayed, please follow the corresponding tips in Chapter 9 to deal with it.
- ※ Do not open the cover of the machine after the soft starter is powered on to avoid electric shock.
- ※ During the trial operation, if abnormal phenomena are found, such as abnormal sound, smoke or peculiar smell, the machine should be stopped quickly, the power supply should be cut off, and the cause should be checked.
- ※ In the case of soft starter output motor is not connected, then U, V, W three-phase induction voltage, is a normal phenomenon, connected to the motor after this induction voltage can disappear.

## **10.2 Matters needing attention in daily maintenance**

- ※ Induction Voltage: When the power supply is connected to the input terminal of the AC motor soft starter, the output terminal of the soft starter will have an induction voltage when the load is open, even when it is stopped. This is caused by the leakage current of the thyristor, which is normal. The induction voltage will disappear after the motor is connected. Therefore, attention should be paid to the risk of electric shock.
- ※ Reactive power compensation: If a reactive power compensation circuit with higher power factor needs to be installed in the distribution circuit, the reactive power compensation capacitor should be connected to the input end of the soft starter, not to its output end; otherwise, the power device of soft starter will be damaged.
- ※ Insulation Test: Do not use megohm meter to measure the insulation resistance between the input and output of the motor soft starter, otherwise the power device and the Control Board of the soft starter may be damaged by overvoltage.
- ※ Circuit Connection: The input and output of the motor soft starter cannot be connected inversely. Otherwise the soft starter or motor may be damaged.
- ※ By-pass contactor wiring: When Motor soft starter is equipped with by-pass contactor, the phase sequence of soft starter output U, V, W and by-pass output L11, L12, L13 must be same.
- ※ External Control Terminal: The External Control Terminal of the AC motor soft starter starts, stops, actuates, resets, and is public. No external power shall be introduced, or the control panel of the soft starter will be damaged.
- ※ In the case of more dust, dust cleaning should be carried out regularly; otherwise

the insulation level and heat dissipation effect of soft starter will be reduced, resulting in failure or damage.

- ※ In a humid environment, such as long-term non-use of soft starter, before use, must be dehumidified treatment (such as drying with a hair dryer or electric oven) , otherwise, as a result of moisture or condensation, reduce the insulation level of soft starter, resulting in creepage, short circuit, damage the soft starter.

## Notice of order

- ※ when ordering, please inform the supplier of the product model, specification, load condition and use condition so as to select the product correctly.
- ※ AC motor external type products should be equipped with bypass contactors.
- ※ For users who have special conditions or requirements for this product, please indicate to the supplier at the time of ordering. We will provide perfect service.
- ※ If the load is wound motor, the order should be stated.

## 11. Structure and outline dimensions of MSS1000-G on-line intelligent soft starter




Specifications	Overall dimensions(mm)			Installation dimension		
	H	W	D	H1	W1	Φ
5.5KW-75KW	282	156	190	267	100	M6
90KW-160KW	384	410	243	360	351	M8
185KW-200KW	434	410	243	410	351	M8
250KW-400KW	494	410	253	460	351	M10
500KW-630KW	612	453	310	590	393	M10
700KW-800KW	702	493	310	690	433	M10

## 12. Structure and outline dimensions of MSS1000 bypass intelligent soft starter

①5.5KW-7.5KW



②90KW-630KW



Specifications	Overall dimensions(mm)			Installation dimension		
	H	W	D	H1	W1	Φ
5.5KW-75KW	273	145	168	245	100	M6
90KW-200KW	385	260	205	358	226	M8
250KW-320KW	409	290	205	380	256	M8
400KW-500KW	427	330	205	440	296	M10
630KW-720KW	467	330	205	440	296	M10



### 13. External dimensions of MSS1000 intelligent soft starter with built-in bypass (N type)

Specifications	Overall dimensions(mm)			Installation dimension		
	H	W	D	H1	W1	Φ
37KW-75KW	305	160	200	290	100	M6
90KW-115KW	368	247	215	352	187	M8
132KW-200KW	560	291	200	535	215	M10

### 14. Specification parameter list of peripheral parts

Softer model	Rated power (KW)	Rated current (A)	(MCCB) (A)	Bypass contactor	Primary line (mm <sup>2</sup> )
MSS1000/005-3	5.5	11	32	MSS1000-16	Copper 2.5
MSS1000/007-3	7.5	15	40	MSS1000-16	Copper 4
MSS1000/011-3	11	23	63	MSS1000-25	Copper 6
MSS1000/015-3	15	30	63	MSS1000-40	Copper 10
MSS1000/018-3	18.5	37	100	MSS1000-40	Copper 10
MSS1000/022-3	22	45	100	MSS1000-63	Copper 16
MSS1000/030-3	30	60	100	MSS1000-63	Copper 25
MSS1000/037-3	37	75	100	MSS1000-100	Copper 35
MSS1000/045-3	45	90	100	MSS1000-100	Copper 35
MSS1000/055-3	55	110	160	MSS1000-160	Copper 35
MSS1000/075-3	75	150	250	MSS1000-160	Cop35/ Alu.50
MSS1000/090-3	90	180	250	MSS1000-250	Cop50/ Alu.70
MSS1000/110-3	110	230	350	MSS1000-250	Cop70/ Alu.95
MSS1000/132-3	132	260	400	MSS1000-400	Cop95/ Alu.120
MSS1000/160-3	160	320	400	MSS1000-400	Cop95/ Alu.150
MSS1000/185-3	185	370	400	MSS1000-400	Cop120/ Alu.185

MSS1000/200-3	200	400	400	MSS1000-400	Cop150/ Alu.185
MSS1000/250-3	250	500	630	MSS1000-630	Cop185/ Alu.240
MSS1000/280-3	280	560	630	MSS1000-630	Cop240/ Alu.300
MSS1000/320-3	320	640	630	MSS1000-630	Cop240/ Alu.400

## Product Warranty Card

Customer info	Company Add:	
	Company name:	Contact:
	Zip code:	Phone:
Product info	Model:	
	Serial number:	
	Agent name:	
Fault info	Maintenance time and content	
	Maintenance person	

Please read the instruction manual carefully to understand the contents for correct installation, circuit connection, operation and maintenance.

The technical specification of this product changes without prior notice.

This manual should be kept until the end of the product;

This instruction manual should be kept in the hands of the actual end user.

